

FCP model	GST100	GST200	GST500/2	GST500/3	GST500/4
Loops	1	1	2	3	4
Address/loop	128	242	242	242	242
Address/panel	128	242	484	726	968

